
OPERATION & MAINTENANCE MANUAL

Enerpac LPHT312

LOW PRESSURE HOT TAPPING MACHINE

Document Number: L4703

Document Revision: A

Document Revision Date: 06 MAR 2023

Document Language: English EN (Original Instructions)



To reduce the risk of injury, user must read and understand the document before use.

Version History

All Enerpac documentation is quality controlled and audited in accordance with **BS EN ISO 9001:2008**; the scope of which covers design, manufacture and repair of in-situ machine tools.

Version No.	Implemented By	Revision Date	Approved By	Approval Date	Comments
1	DRB	13-04-17	DC	13-04-17	1 st Issue
2	STH	08/2020	-	-	Enerpac rebrand
A	STH/ SVO	17/10/2022/ 06/03/2023	DRB/ DC	17/10/2022/ 06/03/2023	Update regarding LPC-3-LP on page 15, updated Gas. Updated drawings LPHT312, added LPHT312-P-M

Operation & Maintenance Manual Approval

The undersigned acknowledge they have reviewed this Machine Operation & Maintenance Manual and agree with the approach it presents. Changes to this Operation & Maintenance Manual will be coordinated with, and approved by, the undersigned or their designated representatives.

Approver 1

Signature:



Date:

13-04-17

Print Name:

Geoff Bull

Title:

Operations Manager

Approver 2

Signature:



Date:

13-04-17

Print Name:

David Cochrane

Title:


Design Manager

1.	Introduction.....	4
1.1.	Overall Equipment Description	4
2.	Machine Warranty.....	4
3.	Health and Safety	5
3.1.	Mandatory Safety Signs (for the purpose of trials at Enerpac)	5
3.2.	Machine Hazards Signs	6
3.3.	Safety Procedures.....	6
3.3.1.	Pre-Operational Safety Checks	7
3.4.	Operational Safety Checks.....	7
3.4.1.	Housekeeping	7
3.4.2.	Potential Hazards.....	7
4.	Handling.....	7
5.	Machine Specification	8
5.1.	General Assembly Drawings	9
6.	Installation	14
6.1.	Machine Set-up	14
6.4.1.	Personnel	19
7.	Machine Operation.....	20
8.	Machine Maintenance.....	21
9.	Troubleshooting Guide	23
10.	Appendices	24
10.1.	Hot Tapping Data Sheet.....	24
10.2.	Recommended torque settings for fasteners	25
10.3.	General Notes.....	26

1. Introduction

1.1. Overall Equipment Description

The LPHT312 is a Low Pressure Hot Tapping Machine featuring a Pneumatically powered boring bar, and a manually operated feed for the cutter assembly.



2. Machine Warranty



See Document Pack.

3. Health and Safety

Enerpac has made every effort to ensure that the Information given in this Operation & Maintenance manual, and other publications relating to this machine is correct and understandable. However it is acknowledged that there may be errors or omissions in this publication.

The company also reserves the right not to provide updates, corrections or amendments to this publication but will endeavour to keep its customers up to date with all changes that may affect the machine operation or safety.

3.1. Mandatory Safety Signs (for the purpose of trials at Enerpac)

ISO 7010 SYMBOL	SAFETY DESCRIPTION
	WEAR EYE PROTECTION
	EAR PROTECTION MUST BE WORN
	HARD HATS MUST BE WORN
	PROTECTIVE GLOVES MUST BE WORN
	PROTECTIVE FOOTWEAR MUST BE WORN
	OVERALLS MUST BE WORN
	MACHINE GUARDS MUST BE USED

3.2. Machine Hazards Signs

ISO 7010 SYMBOL	HAZARD DESCRIPTION
	DANGER HIGH VOLTAGE
	WARNING MOVING MACHINERY
	CAUTION MOVING MACHINERY
	WARNING KEEP HANDS CLEAR

3.3. Safety Procedures

Detailed in this chapter is a list of good Health and Safety practices that Enerpac advise users to adhere to. Due to the nature of portable machine tools, not every eventuality can be catered for and the following is not exhaustive, as such Enerpac strongly advise that the user carries out their own risk assessments based on the machining and environment in which they intend to use the machinery.

3.3.1. Pre-Operational Safety Checks

1. Always read safety signs / labels
2. Ensure no slip / trip hazards are present in workspaces and walkways
3. Locate and ensure you are familiar with the operation of the ON / OFF starter and E-Stop (*if fitted*)
4. Do not leave equipment on top of the machine
5. Ensure each tool is in good condition and securely mounted
6. Secure / Remove loose items
7. Faulty equipment must not be used. **Immediately report any suspect machinery**

3.4. Operational Safety Checks

1. Operator is fully conversant and trained in use of equipment
2. Keep clear of moving machine parts
3. Never leave the machine running unattended
4. Follow correct clamping procedures - keep overhangs as small as possible and check work piece is secure
5. Set the correct speed to suit the tool, the depth of cut and the material
6. Before making adjustments and measurements or before cleaning swarf accumulations switch off and bring the machine to a complete standstill

3.4.1. Housekeeping

1. Switch off the machine
2. Remove milling cutters, drill attachments and tap attachments and store them safely (if applicable)
3. Leave the machine and work area in a safe, clean and tidy state

3.4.2. Potential Hazards

1. Sharp cutters
2. Moving components – hair / clothing entanglement
3. Eye injury
4. Skin irritation
5. Metal splinters and burrs
6. Flying debris

4. Handling

Customers, users and operators of the machines must be aware of the nature of the equipment supplied.

Although inherently robust, the machine is a precision tool and may be damaged by poor handling, tipping and falling, inadequate transport arrangements over e.g. rough terrain, misuse by operators and use outside its design specification.


Such poor handling may result in either broken or damaged parts or disturbance to fine settings resulting in an inability to meet the specified machining tolerances and capabilities.


5. Machine Specification


The Enerpac LPHT312 Low Pressure Hot Tapping Machine has been designed for accurate in-situ machining of work surfaces, to this end the constituent parts are easily manipulated by hand or crane.

Description	Value	
Boring Depth	762mm Max	
Feed Rate	3.5mm/rev	0.137"/rev
Drive Motor Requirements (Max)	2900L/min	6 Bar
Drive Motor Power	4 Hp	3 Kw
Boring Bar Speed (Max)	38 RPM	
Machine Weight (Without cutter assembly)	75.4 Kg	166.2 Lbs
Designed For General Use		

5.1. General Assembly Drawings









Printed on 29-Mar-17

DO NOT SCALE

IF IN DOUBT ASK




ITEM NO.	REV	PART NUMBER	DESCRIPTION	QTY
1		LPHT312-1-001	GEAR HOUSING	1
2		LPHT312-1-002	GEAR HOUSING LID	1
3		LPHT312-1-011	5/8" DRIVE GEAR	1
4		LPHT312-1-012	GEAR SPACER	1
5		LPHT312-1-015	FEED NUT	1
6		LPHT312-1-016	SEAL COVER	1
7		LPHT312-1-017	TOP COVER	1
8	C	HTD0408	GEAR SEAT	1
9	F	HTD0407C	2 1/2" DRIVE GEAR	1
10	A	HTD0533	MOTOR GEAR SPACER	1
11		MB9	LOCK WASHER FOR NOTCHED NUT Ø45	1
12		KM9	LOCK NUT M45 x 1.5	1
13		QFM-3034-37-2	Igildur® Q Flange Bearing	4
14		QSM-3034-20	Igildur® Q Sleeve Bearing	4
15		51107	THRUST BEARING	2
16		32009	SINGLE ROW TAPER ROLLER BEARING	2
17		HK 3512	NEEDLE ROLLER BEARING	1
18		M4 X 10	Hex Socket CTSK Head - BS EN ISO 10642	6
19		M4 x 16	Hex Socket CTSK Head - BS EN ISO 10642	4
20		M5 x 16	Hex Socket Head - BS EN ISO 4762	3
21		M10 x 40	Hex Socket Head - BS EN ISO 4762	9
22		24863	RADIAL SHAFT SEAL	1

REV.	INC.	DESCRIPTION	DATE	DRAWN BY	APPROVED
 THIRD ANGLE PROJECTION			 MIRAGE PORTABLE PERFORMANCE 10 ENTERPRISE WAY, JUBILEE PARKWAY, STORES ROAD, DERBY DE214 8BB TEL (01532) 291767 FAX (01532) 370356 E MAIL info@mirage-machines.co.uk DWG No LPHT312-1 SHEET 1 OF 2		
© MIRAGE MACHINES LTD 2017 ALL RIGHTS RESERVED UNDER COPYRIGHT, DESIGN AND PATENT LAWS NO COPY OF THIS DOCUMENT OR THE ARTICLE SHOWN MAY BE MADE WITHOUT PRIOR WRITTEN PERMISSION					
WEIGHT	13.163kg				
DRAWN BY	DC	23-Mar-17			
CHECKED BY	DC	27-Mar-17			
APPROVED BY					
TITLE					
GEARBOX ASSEMBLY			A3		
SCALE: 1:2					



10 ENTERPRISE WAY, JUBILEE PARKWAY,
STORES ROAD, DERBY DE21 4BB
TEL (01332) 291767 FAX (01332) 370356
E MAIL info@mirage-machines.co.uk

N:\Drawing Storage\MACHINES GA's\HOT TAPPING\LPHT312\LPHT312-1
A3 ASSEMBLY (AUTO) - 7-4-2009



6. Installation

6.1. Machine Set-up

6.2. Fitting Cutters & Pilot Drills


Shown below is data relating to the cutters & pilot drills that are compatible with the LPHT312.

Each cutter has a unique corresponding flange adaptor, and there are three available pilot drills which cover the range of cutters. The correct pilot drill MUST be used with its corresponding cutter. All these cutters & drills are available from Enerpac.


Select the required cutter & pilot drill combination from the list below for your required application.

LPHT312 Standard, Hot Tapping Cutter Data											
Nominal Cutter Size	Actual Cutter Size		Standard Hot Tap Cutters			Standard Hot Tap Pilot Drills			Flange Adaptors		
In	In	MM	Lbs	Kgs	Part No	Part No	Lbs	Kgs	Part No	Lbs	Kgs
3	2.4	61.5	1.1	0.5	LPC-3	LPPD-4	1.1	0.48	150-3FA-3	28.9	13.1
4	3.4	86.9	2.2	1	LPC-4				150-4FA-3	32.8	14.9
6	5.4	137.7	5.5	2.5	LPC-6	LPPD-8	1.3	0.57	150-6FA-3	42.8	19.4
8	7.4	188.5	11.6	5.3	LPC-8				150-8FA-3	67.7	30.7
10	9.4	239.3	18.5	8.4	LPC-10	LPPD-12	1.5	0.67	150-10FA-3	112.2	50.9
12	11.4	290.1	27.6	12.5	LPC-12				150-12FA-3	159.8	72.5


To install the pilot drill, fit the drill into the boring bar and secure with x2 LPHT312-1-021 location pins and tighten them to ensure pilot drill is fixed in place. Note that there are three positions for the location pins in the pilot drill, when using a pilot drill for 3, 6, and 10" cutters the pilot drill must use the closest two locations relative to the drill tip. When using a pilot drill for 4, 8, and 12" cutters, the furthest two positions must be used so that the drill protrudes further out of the boring bar.




A 'Flange adapter' is fitted before the cutter itself. This acts as an adapter between the hot tapping machine & the 'Gate Valve' as well as housing the cutter assembly. Secure the adaptor to the LPHT machine using four 5/8" studs, washers, and UNC nuts.



Extend the boring bar by turning the manual handwheel until the end of the bar protrudes from the 'Cutter Housing', this will allow the cutter to be fitted easily.



To install the cutter, locate the cutter onto the central spigot of the boring bar, rotate it until the four holes align and secure it in place with four M8x30 bolts. Note that the 3" cutter requires the LPHT312-1-023 adapter between the cutter and the boring bar and is secured to the cutter with two additional M6x25 bolts.




Note: The 'Cutter Housing' is not shown to allow the above image to be viewed easily.


When using the 3" Spacer assembly (LPC-3-LP), the M8 x 30mm long extractable dowels on the end of the boring bar, should be changed to the M8 x 50mm long extractable dowels.

6.3. Lifting


The LPHT312 is lifted & installed using a combination of four 'Rotating Lift Points' mounted along the body of the machine as can be seen below.




If not already installed, fit the 'Rotating Lift Points' by screwing them into the machine body.



Tighten the M12 lifting point bolts with a torque wrench to 135Nm (99.5 Lb/ft).



If lifting the machine in a vertical arrangement, with the nose of the machine pointing downwards then only use the rearward mounted lifting points with suitable lifting equipment i.e. overhead crane as shown above.



If lifting the LPHT312 in a horizontal arrangement all four lifting points should be used along with suitable lifting equipment i.e. overhead crane as shown above.

6.4. Securing to pipeline.

What follows is a guideline only, all pipeline connecting scenarios cannot be predicted, therefore a job specific mounting procedure should be constructed before attempting to mount the machine.

The LPHT312 is mounted to a live pipeline via a pre-installed 'Gate Valve'. It is secured by a series of high tensile 1" studs & nuts to the cutter housing or 'Adapter Flange'. The 'Adapter Flange' is then secured to the 'Gate Valve' by a similar series of bolts or studs.

Before making any attempt to secure the LPHT312 to a 'Gate Valve', measurements should be taken to predict how far the cutter should be fed until it has completely cut through one side of the pipe wall. Use the 'Hot Tapping Data Sheet' in the back of this manual to record such measurements.

1. Retract the cutter into the 'Cutter Housing' to prevent it clashing with any of the pipeline assembly whilst lifting the hot tapping machine into place.
2. Fit a new sealing element between the 'Cutter Housing' & the 'Gate Valve'.
3. Safely lift & manoeuvre the LPHT machine until the 'Cutter Housing' is roughly aligned with the 'Gate Valve'.
4. Ensure that before securing the LPHT to the pipeline, it is orientated such that the gearbox controls will be easily accessible when the machine is in place.
5. Align the corresponding holes between the 'Cutter Housing' & 'Gate Valve', insert appropriate studs & nuts & tighten equally using a calibrated torque wrench to the correct torque figure.
6. To make sure the cutter has not been trapped, rotate the manual feed handwheel to check the cutter can move freely up & down the cutter housing.

The LPHT is now properly installed & the Motor hoses can now be connected.

BEFORE STARTING THE MACHINE IT IS THE OPERATORS RESPONSIBILITY TO CHECK THAT ALL CLAMPS AND TOOLS ARE TIGHT AND THAT THE WORKING AREA IS CLEAR OF OBSTRUCTIONS AND DEBRIS


6.4.1. Personnel

As a specialist portable machine the minimum standard for an operator is to be:

- The operator must be trained and conversant with the Enerpac LPHT312
- The operator to be able to identify the correct and incorrect use of static or portable machines
- Comply with all local and internationally recognised safe use of powered machines

7. Machine Operation

1. To position the cutter & pilot drill assembly prior to cutting, turn the manual feed handwheel with the motor turned off & the 'Gate Valve' open until the pilot drill stops when it hits the pipe. Turn the manual feed handwheel the opposite direction five turns to allow a gap between the pilot drill & pipe.
2. Start the cutter rotation by engaging the pneumatic motor, the cutter will now be rotating but not feeding towards the pipe.
3. Use the pre-cut data that should have been recorded on the 'Hot Tapping Data Sheet' at the back of this manual as a guide for how far the cutter needs to be advanced.
4. To start feeding the cutter towards the pipe, begin turning the manual feed handwheel



5. Using the pre-cut data which should have been recorded on the 'Hot Tapping Data Sheet' at the back of this manual, continue to feed the cutter into the pipeline until it has made a complete cut through one side of the pipe.
6. Stop rotating the manual feed handwheel and turn the pneumatic motor off.
7. Retract the cutter by turning the manual feed handwheel in the opposite direction. The pipeline 'coupon' will be retained by the pilot drill, this can be recovered later when the machine is removed from the pipeline.

8. Machine Maintenance


General wear and tear items should be replaced with like for like components as per the machine general assembly drawings detailed in this manual. Failure to do so may result in a machine that is not fit for purpose and is outside the design intent it was supplied for. Items that require specific maintenance regimes and products will be detailed here in.

General Maintenance Schedule		
Time Period	Action	Recommended Lubricant
After every use	Clean all cutting debris from machine. Pay particular attention to lead screws, pivots, sealing, sliding & rotating faces.	General water displacing, cleaning oil.
As required	Replace cutting tool/cutting tool inserts.	N/A
Every 10 hours	Apply a small amount of low viscosity oil to all lead screws, pivots, sliding & rotating faces.	Mineral based SAE 10 oil.
	Check all securing nuts & bolts are tight.	N/A
Every 100 hours	Check for backlash in lead screw/lead screw nut & correct if necessary.	N/A
Before long term storage (12 months minimum)	Protect machine, components & accessories from corrosion. Store all machine components securely in original packing box.	General, oil based, rust inhibitor.


8.1. *Replacing seals*

If low pressure is detected the seals located within the LPHT312-1-004 bottom plate may need replacing. The procedure for achieving this is as follows.

1. Unscrew the four M8x30 screws located within the LPHT312-1-004 bottom plate and remove the bottom plate assembly from the LPHT machine.



2. Unscrew the eight M6x16 screws which secure the LPHT312-1-009 seal cartridge to the LPHT312-1-004 bottom plate.



3. Remove and replace the two R009F 63.5x74.5x4.2 rotary seals and single OR3008200 O-ring. The pressure seals are best installed warm and can be soaked in warm water prior to fitting. They are gently formed into a kidney shape and then eased into the groove and can be pushed around and greased lightly.
4. Re-assemble the LPHT312-1-004 bottom plate by following the reverse of the above instructions.

9. Troubleshooting Guide

Symptom	Possible cause	Action
The machine will not rotate	1. Hydraulic/Pneumatic supply not available	Check supply
	2. Hydraulic/Pneumatic supply is below the minimum required to operate the machine	Check supply
	3. Drive motor faulty	Remove motor and check operation
	4. Damage to drive gear train	Remove motor and check free rotation
	5. Faulty valve or emergency shut off operational	Check supply to motor
The machine does not traverse	1. The feed control valve is not correctly set	Check position
	2. Drive gear problem	Remove and check drive assembly operation
	3. Depth of cut too deep	Remove cut and check rotation

10. Appendices

10.1. Hot Tapping Data Sheet

Customer Details.....Contact Number.....
Contact Details.....Date / Time.....

Tap Details.

Tap Size.....
Flange Rating.....
Orientation.....
Branch wall Thickness.....
Valve Type.....
Bore Details.....

Pipe Details.


Pipe Size.....
Wall Thickness.....
Material.....
Product Type.....
Pipe Pressure.....
Temperature.....

Flow rate-.....Customer Signature.....
Recommended Flow rates, Gas 20mph; 30fps; 10m/s. Liquids 10mph; 15fps; 5m/s.

Tapping Machine Operational Checks.

Tapping adapter bolts secure.....Y/N
Cutter holder screws secure.....Y/N
Cutter retaining screws secure.....Y/N
Pilot drill / retaining screws secure....Y/N

Boring Bar Alignment Check.



Check Boring bar is central to Hot Tapping Adapter Y/N

Hot Tapping operation Dimensions.


A, Flange to pipe =.....
B, Top valve to gate =.....
C, Pilot drill to flange =.....
D, Cutter to flange =.....
E, Coupon cut depth =.....

Hot Tapping Cutting Distances.

Pilot Drill to pipe, $A+C$ =.....
Cutter to Pipe, $A+D$ =.....
Total Cut Distance, $A+D+E$ =.....
(E =Ref Coupon Distance Chart).

Valve Details.

Valve Flange to Gate B =.....
Number of turns to close / open



Technician Signature.....Customer Signature.....
Date.....Date.....

10.2. *Recommended torque settings for fasteners*

Thread Ø	Tensile Strength		Torque Setting	
	kN	lbs	Nm	in - lbs
M3	6.54	1470	2.1	19
M4	11.4	2560	4.6	41
M5	18.5	4160	9.5	85
M6	26.1	5870	16	140
M8	47.6	10700	39	350
M10	75.4	17000	77	680
M12	110	24700	135	1200
M14	150	33700	215	1900
M16	204	45900	330	2900
M20	306	68800	650	5750
M22	374	83950	875	7725
M24	441	99100	1100	9700
M30	701	158000	2250	19900
M32	860	193500	3050	27000
M36	1020	229000	3850	34100

10.3. General Notes

[illegible]