

L1855 Rev. O 02/94

SERVICE INSTRUCTIONS: These *Service Instructions* are intended to be used by qualified personnel at Authorized Enerpac Service Centers. Users of Enerpac equipment should refer to the wrench *Instruction Sheet* for installation, operation, and maintenance information.

IMPORTANT: To avoid any unnecessary service, all valves should be tested prior to any service work. This procedure is intended for use in conjunction with torque wrench pump repair parts sheet numbers L1751, L1753, L1757, L1849, or L1850.

Items needed for testing:


- ✓ Repair parts sheet L1751, L1753, L1757
L1849, or L1850
- ✓ Remote valve block
(Enerpac part number CM269885)
- ✓ Variable voltage power supply
- ✓ 10,000 psi hand pump
- ✓ Allen wrenches
- ✓ O-ring pick
- ✓ 15,000 psi gauge
- ✓ Enerpac V8 shutoff valve or equivalent
- ✓ High pressure hose
(10,000 psi rated working pressure)
- ✓ Box end and open end wrenches
- ✓ Special Tools—see pages 2 and 3

CONTENTS

Special Tool Drawings	2	Valve Identification	4
• Tool Assembly	2	Troubleshooting	4
• Pusher Pin	2	Internal Leakage Test Procedure	5
• Pusher	2	Valve Disassembly Procedure	6
• Guide	3	Poppet Assembly Procedure	6
• Sizing Ring	3	Valve Assembly Procedure	7
• Assembly Guide	3	Spring Setting Procedure	8
Valve Function	4		


■ Special Tool Drawings

Tool Assembly




Tool No. AT101667-1 Pusher Pin

Material: low carbon C.D.S.




Tool No. AT101667-2 Pusher

Material: delrin




Tool No. AT101667-3 Guide

Material: low carbon C.D.S.




Tool No. AT101667-4 Sizing Ring

Material: low carbon C.D.S.



Tool No. AT101667-5 Assembly Guide


Material: delrin



■ Valve Function

The Enerpac poppet valve design concept is based on creating a metal-to-metal seal between a poppet and a sharp-edged, round seat. The pressure acting on the poppet is offset by force created by the same pressure acting on the bushing area of the valve, resulting in a hydraulically balanced design. The shift force requirements are thus minimized allowing the use of

smaller solenoids to actuate the valve. The poppet-to-seat interface is the most critical part of this design. Roundness is very important and any distortion of these surfaces causes leakage, especially as the oil temperature rises. Due to the critical nature of these parts they must be replaced as a set.



■ Valve Identification

There are two different valves used on Enerpac torque wrench pumps. The only difference between these two valves is the solenoid voltage.

■ Troubleshooting

The two possible functional problems which may occur over time are the failure to shift (or return) and leakage (internal or external).

Failure to shift, barring some obvious internal breakage, would be the result of solenoid or spring failure. The spring force on each unit is optimized by adjustment of the set screw on the end opposite the solenoid. Tampering with this setting could also result in a failure to shift (see spring setting procedure). The solenoid has a manual override button in the center of the core which can be used to aid in troubleshooting.

If a valve fails to actuate, push the manual override button on the solenoid to actuate. If actuation is

achieved, the coil is likely failed and should be replaced. If the valve fails to return, the spring is likely failed or maladjusted and should be adjusted or replaced (see spring setting procedure).

Leakage can occur internally from one side of the valve to the other due to a worn or failed o-ring on the outside diameter of the seats or a bad sealing surface at the poppet-seat interface. External leakage can occur through the filters on the outside of the valve body if the o-ring on the outside diameter of the bushing is worn or failed. Leakage may also occur if the glyd-ring on the bushing end of the poppet is cut, worn, or extruded.

Pump Model			Valve Model	Solenoid Voltage
PME10027 PME10047 PME10427 PME10447	PMU10027 PMU10047 PMU10427 PMU10447	PME30487	VSG2310P-12000	115V 1PH 50/60Hz
PME10022 PME10042 PME10422 PME10442	PMU10022 PMU10042 PMU10422 PMU10442		VSG3510P-12000	220V 1PH 50/60Hz


■ Internal Leakage Test Procedure

IMPORTANT: The valve-to-remote valve block interface is not keyed making it possible to mount the valve either *forward* or *backward*. As a result, you should label the valve and the remote valve block ports before performing this test. See the section below for the labeling procedure.

Remote Valve Block (CM269885):

Label valve and valve block as follows:

1. Find path that runs straight through the valve block. The path can be identified by passing air or light through the block.
2. Orient the valve block as shown at right.
3. Label ports A, B, and C, and plug the remaining port.
4. Orient the valve with the solenoid side facing to the left. Before removing solenoid from valve, label the solenoid side of the valve.
5. Mount the valve on the valve block.



To test the valve for internal leakage it will be necessary to use a hand pump, shut-off valve, gauge, and hose. The gauge must be installed between the shut-off valve and the valve being tested.

Test the valve as follows:

1. With the ports (B) and (C) vented to atmosphere, apply 10,000 psi to the port closest to the solenoid end of the valve (A). A gauge must be installed in-line on the pressure supply line. Close the shut-off valve to isolate from the pressure source (hand pump). There may be a short seat-in period, then the valve should hold and the gauge should indicate zero leakage.

2. Release pressure using hand pump.
3. With ports (A) and (B) vented to atmosphere, energize the solenoid and apply 10,000 psi to the port opposite the solenoid end of the valve (C). A gauge must be installed in-line on the pressure supply line. Close the shut off valve to isolate from the pressure source (hand pump). There may be a short seat-in period, then the valve should hold and the gauge should indicate zero leakage.

If internal leakage is found, check the seat, o-rings, and poppet-seat interface and replace if necessary.

■ Valve Disassembly Procedure

Important
The four o-rings (item 4) are not reusable and must be replaced whenever the valve is serviced.
The poppet assembly is a pretested unit and must be replaced as a set.
Make note of which sides the solenoid assembly (item 13) and valve plug (item 1) are located. See page 5 for labeling notes. This will be necessary for reassembly. If these items are incorrectly installed during reassembly, the valve will not operate properly.

1. Remove the solenoid assembly (item 13) from the valve block (item 11).
2. Remove the valve plug and spring (items 1 & 2) from the valve block (item 11). Remove the set screw (item 10) from the valve plug (item 1).
3. Remove the o-rings (item 12) from the valve block (item 11).
4. Use a pick to remove the filters (item 9) from the valve block (item 11).

■ Poppet Assembly Procedure

Important
The poppet seats will tear the glyd-rings (items 7,8) when removed or installed onto the poppet.
The assembly procedure must be followed in exact order to insure proper assembly.
When a new poppet assembly (service part from Enerpac) is used for repair, it will have the glyd-rings installed at the factory. These units are pretested and require no further attention prior to assembly.
The glyd-ring assembly and sizing tools are required for this procedure.

Important
It will be necessary to use the assembly guide (part number AT101667-5) to remove the remaining components.

5. Lay the valve block on a flat surface, with the poppet vertical, allowing room underneath for the internal components to slide out.
6. Use the assembly guide and small hammer to remove the poppet assembly, spacers, and o-rings (items 6,5 & 4) from the valve block (item 11). Discard the o-rings at this time.
Note: Keep the guide flat and concentric while lightly tapping with a small hammer. If the poppet, spacers, and o-rings seem to be stuck or jammed, gently blow shop air into the center port on the valve block to loosen.
7. Remove o-rings and glyd-rings (items 7 & 8) from the poppet assembly (item 6).

1. Install the center spacer (item 5) onto the poppet.
2. Install the two seats onto the poppet with the tapered ends facing away from the center spacer (item 5).
3. Install the o-rings (item 7) onto both ends of the poppet.
4. Use the glyd-ring assembly tools (lubricate with a light grease) to push the glyd-rings (item 8) onto poppet over the o-rings.
5. Lubricate the sizing ring and slide over the glyd-rings (item 8) and leave in place for 1 minute. This will help the glyd-rings form back to their original shape.
6. The poppet assembly is now ready for reassembly into the valve.

■ Valve Assembly Procedure

Important

The four o-rings (item 4) are not reusable and must be replaced whenever the valve is serviced.

The poppet assembly is a pretested unit and must be replaced as a set.

The assembly guide (part number AT101667-5) is required for this procedure.

1. Insert the filters (item 9) into the valve block (item 11). Use a punch and insert until flush.
2. Install the solenoid core (item 13) into the valve block (item 11). Leave hand tight at this time. Do not install the coil and retaining nut at this time (items not numbered).
3. Gently clamp the valve block in a vise. Use soft jaws and make sure the solenoid end is facing down.
4. Place the bushing into the valve block bore with the grooved end facing down.
5. Insert o-ring (item 4) on top of the bushing. Tap the o-ring and bushing down using the assembly guide.
6. Insert the spacer and tap into place using the assembly guide.
7. Insert o-ring (item 4) and tap into place using the assembly guide.
8. Insert the preassembled poppet assembly (item 6) and tap into place using the assembly guide. See separate poppet assembly procedure.
9. Insert o-ring (item 4) and tap into place using the assembly guide.
10. Insert the spacer and tap into place using the assembly guide.
11. Insert o-ring (item 4) and tap into place using the assembly guide.
12. Place the bushing into the valve block bore with the grooved end facing up.
13. Install the spring (item 2).
14. Install the valve plug (item 1) and set screw (item 10). The valve plug should not be torqued at this time. Apply Loctite #222 to the set screw .

IMPORTANT: Be sure to torque the solenoid core BEFORE torquing the valve plug.

15. Torque the solenoid core (item 13) to 15-20 ft-lbs.
16. Torque the valve plug (item 1) to 32-35 ft-lbs.
17. Install the solenoid (item 13) and plastic retaining nut onto the coil and hand tighten.

continued ...

■ Spring Setting Procedure

Each valve leaves the factory with the return spring force adjusted to optimize the force balance in the valve. When any valve part is replaced (other than seals), the spring setting should be checked and adjusted if necessary.

NOTE: This procedure requires a variable voltage power supply.

IMPORTANT: After setting the spring, check for internal leakage. The procedure is on page 5.

Test Voltages For Spring Setting Procedure		
Model Number	Rated Voltage	Test Voltage
VSG2310P-12000	115 VAC	72 VAC
VSG3510P-12000	193 VDC	120 VDC

For the VSG2310P-12000 and VSG3510P-12000:

NOTE: Prior to set screw installation or adjustment, Loctite 222 or equivalent should be applied to the threads.

1. Turn the spring adjusting screw inward until solid.
2. Apply 10,000 psi to the port closest to the solenoid end (A) with ports (B) and (C) vented to atmosphere. A gauge must be installed in-line on the pressure supply side.
3. Apply 60-65% of rated voltage to the coil. See table at left.
4. Slowly back out the spring adjusting screw until the pressure drops to zero. It may start to drop slowly, then suddenly drop to zero. Be prepared for a sudden spray of oil from the open ports.

Australia

Enerpac
Block V, Unit 3
Regents Park Estate
391 Park Road
Regents Park NSW 2143
Tel: (61) (2) 743-8988
Fax: (61) (2) 743-8648

Canada

Enerpac
13000 West Silver Spring Drive
Butler, Wisconsin 53007, USA
Tel: (800) 426-4129 User
Tel: (800) 426-2284 Distributor
Fax: (414) 781-1049

Eastern Europe and Other European Countries, Middle East and Africa

Enerpac
47, avenue Blanc
P.O. Box 67, CH-1211
Geneva 21, Switzerland
Tel: (41) 22-731 94 05
Telex: 22-41 2843
Fax: (41) 22-731 12 15

Far East

Enerpac
47 Jalan Pemimpin
#01-02 & 01-03
Sin Cheong Building
Singapore 2057
Thomson Road P.O. Box 114
Singapore 9157
Tel: (65) 2581677
Telex: RS24882 APOWR
Fax: (65) 2582847

France

Enerpac
B.P. 200
Parc d'Activités du Moulin
de Massy
91882 Massy Cedex, France
Tel: (33) 1-69 20 70 70
Telex: 600 951
Fax: (33) 1-69 20 37 50

Germany

Enerpac
Mündelheimer Weg 51
P.O. Box 300 113
D-4000 Düsseldorf 30
Tel: (49) (221) 41707-0
Telex: 8582790
Fax: (49) (211) 4170740

Italy

Enerpac
Via Canova, 4
20094 Corsico
Milano, Italy
Tel: 39-2-4582741
Telex: 352337
Fax: 39-2-48601288

Japan

Enerpac
10-17 Sasame
Kita-cho, Toda-Shi
Saitama 335,
Japan
Tel: 81-0484-22-2251
(Administration Dept.)
0484-21-2311 (Sales Dept.)
Telex: J26275
Fax: 82-0484-22-0596

Latin America and Caribbean

Enerpac
13000 West Silver Spring Drive
Butler, Wisconsin 53007
Tel: (414) 781-6600 ext. 263
Fax: (414) 781-5561

Mexico

Enerpac
Blvd. Gral. Felipe Angeles 1604
P.O. Box 362
Pachuca, Hidalgo 42080
Mexico
Tel: (52) 771 3-3700 or
Telex: 17 55 15
Fax: (52) 771 3-1196 or
(52) 771 8-3800

Netherlands, Belgium, Luxembourg

Enerpac
Storkstraat 25/P.O. Box 269
NL-3900 AG Veenendaal
Holland
Tel: (31) 8385 35911
Fax: (31) 8385 25613/26645

South Korea

Enerpac
163-12, Dodang-Dong,
Choong-Ku,
Buchun-Shi, Kyunggi-Do
Republic of Korea
Tel: (82) (32) 6560836/7
Fax: (82) (32) 6563002

Spain

Enerpac
Calle de La Imprenta, 5
Poligono Industrial
28100 Alcobendas, Madrid
Spain
Tel: (34) 1-6611125
Fax: (34) 1-6614789

United Kingdom

Enerpac
Leacon Road
Ashford, Kent
TN23 2TU
England
Tel: 4-4233-639871
Telex: 966 450
Fax: 4-4233-643923

United States

Enerpac
13000 West Silver Spring Drive
Butler, Wisconsin 53007, USA
Tel: (414) 781-6600
1-800-433-2766 (End User)
1-800-558-0530 (Distributor)
Fax: (414) 781-1049



All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them. Under this guarantee, free repair or replacement will be made to your satisfaction.

For prompt service, contact your Authorized Enerpac Service Center or call toll free:

**In U.S.A. 1-800-558-0530
In Canada 1-800-426-2284**



PRINTED IN U.S.A.