



MOTOR



NOTES:

1. GROUND BASE TO BAND.
2. LEAD COLORS ARE OPTIONAL. LEADS MUST ALWAYS BE NUMBERED AS SHOWN.


STARTER BRACKET CONDUIT BOX



NOTE:

BALDOR LABEL ON STARTER INDICATES
FACTORY VOLTAGE.

STARTER



NOTE:

INTERCHANGE ANY TWO LINE LEADS TO
REVERSE ROTATION.

REV. DESC: REVISE TO SHOW OPTIONAL COLORS

REV. LTR: B BY: JLP REVISED: 05/05/99 11:46 TDR: 0179909

BALDOR ELECTRIC Co.

6SZ0DQ

FILE: AAA00051766

MDL: -

MTL: -

3PH, SV, 3 LEAD, GRINDER OR BUFFER W/MANUAL STARTER