


Repair Parts Sheets	Revision	Revision Date	Product Code Beginning
L4368	Rev. A	12/2018	A



**Note: See Page 2
for parts list.**

Remark Nr	Description
1	Torque to 23-28 ft-lbs [32-38 Nm]
2	Torque to 40-60 ft-lbs [55-81 Nm]
3	Torque till reach mechanical stop
4	Apply Loctite 545 Thread Sealant

Repair Parts List			L4368
Item	Description	Qty.	Part Number
1	O-Ring-1", 1-3/16", 3/32", Disogrin, 92 Duro	1	●
2	O-Ring-1-3/8", 1-1/2", 1/16", NBR, 70 Duro	1	●
3	Base	1	B180006030
4	Plunger	1	B180006040
5	Internal Rod	1	B180006040-2
6	Stop Ring	1	B180006044-2
7	Spring	1	B180006108
8	Piston Seal 48X41.8x4.8 B180006ref-90	1	●
9	Rod Seal 25.4X31.6x4.8 B180006ref-90	1	●
10	Back Up Ring 25.4 X 29.9 X 1.4	1	●
11	Din472 Retaining Ring Diam 28	1	CCA1028044-1C
12	Caution Decal ■	1	●
13	Enerpac Decal 2.52" X 0.39" ■	1	●
14	Cylinder Half-Female C604	1	CR400
16	Reducer Connector	1	FZ1055
Notes: ● Indicated item included in and available only as a part of the Service Kit RWH101B100K ■ Not shown in the drawing			



To maintain your warranty:

- Have your products inspected and repaired by an Enerpac Authorized Service Center

ENERPAC 

Visit www.enerpac.com for the location of the Enerpac Authorized Service Center nearest you.